


FL511 FL811 FL812

* See Bulletin Z5/86


* 2/9/85

CABINET ASSEMBLY



FL511 FL811 FL812


LID & FASCIA




C10

FL511 FL811 FL812

DRUM ASSEMBLY




WASH COMPONENTS



FL511 FL811 FL812

ELECTRICAL COMPONENTS



FL511 FL811 FL812

REF	PART N°	DESCRIPTION	FL511	FL811	FL812
001	50099716008	Cabinet	*	*	*
002	50097306000	Boss	*	*	*
003	50064857001	Flange	*	*	*
004	50099222007	Spring	*	*	*
005	50099221009	Pin	*	*	*
006	50099717006	Handle (Up to May 85)	*	*	*
006	50099628005	Handle (From May 85)	*	*	*
007	50067919006	Spring (Up to May 85)	*	*	*
008	50654362008	Hook	*	*	*
009	50654713002	Slider (Up to May 85)	*	*	*
010	50097040005	Door	*	*	*
011	50097055003	Pin	*	*	*
012	50097047000	Spring	*	*	*
013	50097477009	Spanner	*	*	*
014	50652436002	Foot	*	*	*
015	50652435004	Spring	*	*	*
016	50652438008	Wheel	*	*	*
017	50652437000	Pin	*	*	*
018	50097269000	Clip	*	*	*
019	50097064005	Clip	*	*	*
020	50099669009	Flange	*	*	*
021	50097052000	Glass	*	*	*
022	50099688009	Porthole	*	*	*
023	50097128008	Hinge	*	*	*
024	50113695006	Spacer	*	*	*
100	50099623006	Control Panel	*	*	
100	50099624004	Control Panel			*
101	50097039007	Top	*	*	*
102	50099622008	Conveyor	*	*	*
103	50098360006	Cam	*	*	*
104	50099700002	Indicator			*
105	50099621000	Indicator			*
106	50099629003	Pushbutton			*
107	50099639002	Control Panel	*	*	
107	50099646007	Control Panel			*
108	50099643004	Indicator	*	*	
108	50099644002	Indicator			*
109	50653112008	Spring	*	*	*
110	50099627007	Knob	*	*	*
111	50099625001	Knob	*	*	*
120	50099569001	Pushbutton	*	*	*
121	50099617008	Button	*	*	*
122	50099650009	Programme Plate			*
123	50099687001	Drawer Fascia			*
123A	50099638004	Drawer Fascia		*	
123A	50099637006	Drawer Fascia	*		
124	50098805000	Spring			*

REF	PART N°	DESCRIPTION	FL511	FL811	FL812
125	50099640000	Drawer Front			*
125	50099641008	Drawer Front	*	*	
126	50099697000	Front Piece			*
127	50099620002	Button	*	*	
128	50099619004	Side Plate	*	*	
129	50099571007	Lens	*	*	
220	50044046006	Nut	*	*	*
221	50042609003	Washer	*		
221	50097272004	Washer		*	*
222	50095641002	Washer	*	*	*
223	50097051002	Counterweight	*	*	*
224	50103620006	Bolt	*	*	*
225	50654754006	Spring	*	*	*
226	50097337005	Bush	*	*	*
227	50097993005	Tub	*	*	*
229	50099327004	Drum	*		
229	50097134006	Drum		*	*
230	50097319003	Clamp	*	*	*
231	50097106004	Gasket	*	*	*
232	50097041003	Flange	*	*	*
233	50068763007	Gasket Ring	*	*	*
234	50097072008	Clamp	*	*	*
235	50097107002	Door Gasket	*	*	*
236	50099059003	Counterweight	*	*	*
237	50064833002	Sleeve	*	*	*
238	50064860005	Bush	*	*	*
239	50068978001	Bolt	*	*	*
240	50063341007	Damper Pad	*	*	*
241	50061337007	Lining	*	*	*
242	50061543000	Washer	*	*	*
243	50098392009	Clip	*	*	*
244	50098391001	Washer	*	*	*
245	50098440006	Spacer	*	*	*
247	50653999008	Spring	*	*	*
247A	50097092006	Buffer	*	*	*
247B	50097093004	Nut	*	*	*
253	50098704005	Seal	*		
253	50061783002	Seal		*	*
254	50098717007	Gasket	*		
254	50095515008	Gasket		*	*
255	50061782004	Bearing	*		
255	50061408006	Bearing		*	*
256	50098715001	Spider Assy	*		
256	50097387000	Spider Assy		*	*
257	50061782004	Bearing	*		
257	50061479007	Bearing		*	*

FL511 FL811 FL812

REF	PART N°	DESCRIPTION	FL511	FL811	FL812
258	50097668003	Pulley	*	*	*
259	50651604006	Belt	*		
259	50068393003	Belt		*	*
260	50043453005	Screw	*	*	*
261	50097585009	Washer	*	*	*
262	50068303002	Washer	*	*	*
321	50098453001	Drain Hose	*	*	*
322	50658062000	Hose Clamp	*	*	*
323	50651839008	Washer	*	*	*
325	50097608009	Hose	*	*	*
326	50099489002	Piston	*	*	*
327	50097086008	Lever	*	*	*
328	50097264001	Spring	*	*	*
329	50097061001	Boss	*	*	*
330	50097070002	Knob	*	*	*
331	50097090000	Connecting Rod	*	*	*
332	50097351006	Guide	*	*	*
333	50097034008	Plate	*	*	*
334	50097099001	Hose	*	*	*
335	50097214006	Filter	*	*	*
336	50098331007	Lever	*	*	*
337	50097607001	Hose	*	*	*
338	50654413009	Bush	*	*	*
339	50654414007	Soap Dispenser Top	*	*	*
339A	50098330009	Spring	*	*	*
340	50098334001	Container	*	*	*
341	50097098003	Hose	*	*	*
342	50064867000	Clip	*	*	*
343	50098332005	Soap Drawer	*	*	*
344	50097217009	Rod	*	*	*
345	50098967008	Insert	*	*	*
346	50099109006	Cap	*	*	*
347	50098974004	Filter	*	*	*
348	50099452000	Gutter	*	*	*
349	50099036001	Gasket	*	*	*
350	50099453008	Filter Housing	*	*	*
351	50099035003	Hose	*	*	*
352	50064867000	Clip	*	*	*
353	50098979003	Air Chamber	*		
353	50099501004	Air Chamber		*	*
355	50097101005	Hose	*	*	*
356	50097229004	Hose	*	*	*
357	50097622000	Hose	*	*	*
358	50098515005	Clip	*	*	*
420	50099519006	Timer	*	*	*
421	50062717009	Pipe	*		
421	50099502002	Pipe		*	*
421A	50099521002	Insert	*	*	*
423	50099648003	Keyboard			*
423A	50099647005	Keyboard	*	*	
424	50652882007	Interlock Switch	*	*	*

FL511 FL811 FL812

REF	PART N°	DESCRIPTION	FL511	FL811	FL812
426	50099251006	Pump	*	*	*
427	50097329002	Fan	*	*	*
428	50096684001	Pulley	*		
428	50096529008	Pulley		*	*
429	50097610005	Motor	*		
429	50098384006	Motor		*	*
430	50095563008	Gasket	*	*	*
431A	50103850009	Thermostat			*
431B	50068705008	Thermostat	*	*	
432	50099496007	Element	*	*	*
433	50651943008	Thermostat	*	*	*
434	50099563008	Gasket	*	*	*
435	50099504008	Valve	*	*	*
436	50099633005	Valve	*	*	*
437	50098446003	Junction Box	*	*	*
438	50096576009	Capacitor	*		
438	50653127006	Capacitor		*	*
439	50098721009	Capacitor	*	*	*
441	50097121003	Pressure Switch	*	*	
441	50097473008	Pressure Switch			*
442	50097940006	Pilot Lamp	*	*	*