SPARE PARTS LIST

Stick Rechargeable

0920

Item	PNC	ELC	Brand	Model	Market
A	900275984	00	Electrolux	ZB3103	THE
A	900275990	00	Electrolux	ZB3114AK	SEA
A	900275986	00	Electrolux	ZB3107	SEA
A	900275988	00	Electrolux	ZB3113	SGH/MYH

SAFETY WARNING

Always turn off and unplug the machine before detaching any parts.

When servicing machines, do not remove
ANY detachable parts while the machine is powered.
The reason is internal faults may cause shorts to components
that are normally at low voltage presenting a shock hazard.


Small Appliance
Vacuum Cleaner
Stick Rechargeable

Electrolux SEA Pte.,Ltd.

Publication-No.
150901

Model	PNC
ZB3103	900275984
ZB3114AK	900275990
ZB3107	900275986
ZB3113	900275988

Ex. View Drawing Housing, Motor and Filter



PNC	ELC	Brand	Model	Market
900275984	00	Electrolux	ZB3103	THE
900275990	00	Electrolux	ZB3114AK	SEA
900275986	00	Electrolux	ZB3107	SEA
900275988	00	Electrolux	ZB3113	SGH/MYH

Pos.	Description	Part Code	ZB3103 (10.8V) PNC: 900275984	ZB3114AK (18V) PNC: 900275990	ZB3107 (14.4V) PNC: 900275986	ZB3113 (18V) PNC: 900275988
001	Small brush nozzle	100480640412010	•	•	•	•
002	Crevice nozzle	100480630361011	•	•	•	•
003	Battery kit	988263008		•		•
003	Battery kit	988262008			•	
003	Battery kit	988261017	•			
004	Locking screw	31004065	•	•	•	•
005	Floor stand	988263030		•	•	•
005	Floor stand	988261018	•			
006A	Clip joint nozzle	100180630091020	•	•	•	•
006B	Clip joint (ring)	100780630571010	•	•	•	•
007	Roller brush cover	988063006	•	•	•	•
008	Led kit (Led+pcb, wiring, holder)	988068064	•	•	•	•
009	Hose kit	988063007	•	•	•	•
010	Roller brush, complete	988262003	•	•	•	•
011	Small wheel kit (2 pcs.)	988262004	•	•	•	•
012	Large wheel kit (2 pcs.)	988063011	•	•	•	•
013 & 014	Brush motor+PCB Driving belt kit	988263002		•		•
013 & 014	Brush motor+PCB Driving belt kit	988262001	•		•	
015	Driving belt	500148063010	•	•	•	•
016	Handheld unit without dust container	988263023		•		•
016	Handheld unit without dust container	988262028			•	
016	Handheld unit without dust container	988263026		•		
016	Handheld unit without dust container	988261021	•			
017	Dust container without filters	988263005		•		
017	Dust container without filters	988262019			•	
017	Dust container without filters	988263006				•
017	Dust container without filters	988261001	•			
018	Outer filter	100480630101010	•	•	•	•
019	Inner filter	988262005	•	•	•	•
020	Switch cover for hand unit	100180680071032	•	•	•	•
021A	Button On/Off	100180630072030	•	•	•	•
021B	Button Power Up/Down	100180630062030	•	•	•	•
	Handheld unit	988263022				•
	Handheld unit	988262029			•	
	Handheld unit	988263024		•		
	Handheld unit	988261020	•			
	Floor Unit completed	988263035		•		
	Floor Unit completed	988262024			•	
	Floor Unit completed	988263025				•
	Floor Unit completed	988261016	•			
022	Hose Unit	988263011		•		
023	Crevice nozzle Unit	988263013		•		
024	Bed Assembly Unit	988263014		•		
025	Nozzle Unit	988263012		•		
	PCB Main	938263004		•		•
	PCB Main	938262004			•	
	PCB Main	938261002	•			
	Suction motor assy	988068053	•	•	•	•